



Instructions for Porsche Go Pro Style Camera Mount All Models

Parts Included-

1-Camera Mount

1-M6 Bolt

2-Washers

1-Wing Nut



1) Locate roof rack mounting door



2) Open roof rack mounting door remove plastic screw

3) Insert go pro pivot arms onto mount using the supplied washers and M5 wing nut to secure arm to mount.



4) Install mount into roof rack mounting door and start bolt by hand and then tighten with 5mm Alan Wrench.

5) Adjust camera to selected angle and tighten go pro bolts to lock in place. You are now ready to hit hit record and start taking video

